



PermaroofUK[®]
The Permanent Roof People Limited

Fitting A Gutter Edge Backplate

www.permarroof.co.uk

Fitting A Gutter Edge Backplate

In this tutorial, we're going to guide you on the fitting of the gutter edge back plate.

Step 1

We're going to remove the existing EPDM sheet that's overhanging of the gutter edge.



Step 2

Temporarily place the gutter edge back plate in position, to put the screws in, just to start them off.

There's a recess in the backplate that will allow the screws to go in. The spacing on these screws are approximately 400mm.



Step 3

Once you've got all the screws in place, just offer the backplate over the side, making sure that the top edge of the backplate does not protrude higher than the level of the roof deck.



Step 4

Now just nip the screws up securely to make sure that the backplate stays in position.



**For more guides, videos and
downloads please visit:
www.permarroof.co.uk**

**Buy online:
www.permarroofstore.co.uk**