



Application Guides

P500 Liquid PU Roofing: Top Coat UV

We offer a range of roofing and building solutions to tradesmen, stockists, and directly to consumers. Long term solutions to age old problems. Partnering with some of the biggest names in the industry, we have a long history of quality and excellence.



 www.permarroof.co.uk

 sales@permароof.co.uk

 01773 608839

Permaroof500 Liquid PU Guides

Application of P500 Liquid Top Coat UV

In this guide, we are going to show you how to apply the Permaroof500 liquid PU waterproofing system topcoat UV layer.

Please note that detailed and main area applications should be undertaken first.

Further application guides are available in the Permaroof resource library, including a full, step-by-step guide to complete application of the innovative waterproofing system for flat roofing. Permaroof UK Ltd also have an extensive video library, packed with detailed tutorials for complete application of liquid waterproofing.

Find the full installation guide at:

permaroof.co.uk/diy-flat-roof-library

Each step of the application process is also available separately in individual guides.

Shop online for the P500 liquid PU waterproofing system at:

permaroofstore.co.uk/liquid-roofing



Permaroof500 Topcoat UV is pre-measured in 1.3l tin part A, and 1.7l tin part B. Both tins can be mixed together fully and applied for a coverage of 150g/m² or 25m². Mixing ratio of 6parts A:1part B for smaller areas. Mix until the two products are fully blended.





You will notice that the colour becomes slightly lighter when fully blended.



Add the blended product to a suitable container.



The pot life of the mixed product is approximately 6 hours.



Using a roller, apply the Permaroof500 Top Coat UV to the entire surface of your working area, making sure coverage is complete.



Permaroof500 Top Coat UV is also self-levelling, so there is no need to overwork the product.



Additional information:

- For car parks and high traffic areas, apply two layers of P500 Topcoat UV.
- Allow each layer to dry and cure fully before applying the next.
- It will dry in around 1-2 hours depending on the weather.

Permaroof500 liquid waterproofing can also be used to effectively create anti-slip surfaces to increase safety for certain types of use:

- External staircases or steps
- Balconies
- Safe walking surfaces in nurseries, schools and homes for the elderly
- Balconies
- Swimming pool areas
- Car parks

This involves adding a medium to the P500 topcoat UV layer. Please refer to the guide for creating anti-slip surfaces in the Permaroof resource library (see links below).

Permaroof UK Ltd

01773 608 839

permaroof.co.uk

Shop online

permaroofstore.co.uk

EPDM roofing training:

permaroof.co.uk/roofing-training-courses

Further EPDM resources:

permaroof.co.uk/diy-flat-roof-library

Visit our YouTube channel for tutorials:

youtube.com/user/PermaroofOnline/videos