



Installation Guides

Roof in a Box Fitting Instructions

We offer a range of roofing and building solutions to tradesmen, stockists, and directly to consumers. Long term solutions to age old problems. Partnering with some of the biggest names in the industry, we have a long history of quality and excellence.



 www.permarroof.co.uk

 sales@permароof.co.uk

 01773 608839

Roof in a Box Fitting Instructions



In this guide, we will demonstrate the application process for fitting your Permaroof in a Box roof kit. Our roof kits include everything you need to replace the roofing on your shed, garage or home extension. Fast and easy to apply, ideal for DIY.

This step-by-step guide highlights the method used for applying the liquid adhesive with a roller. For application instructions for kits with spray adhesive, please visit the Permaroof resource library to download your copy.

Visit the Permaroof resource library at:

permaroof.co.uk/diy-flat-roof-library

Buy standard or cut-to-size flat roof kits at:

permaroofstore.co.uk/roof-kits

Permaroof in a Box[®] Fitting Instructions

Step 1

Open the box to check contents and familiarise yourself with the components.



You should have:

- Membrane
- Adhesive (spray or liquid)
- Roller (if liquid adhesive)
- Sealant
- Latex gloves
- Polypins

Step 2

Place membrane over roof, ensuring you have full coverage.



Allow to relax for 30 minutes.

Step 3

Fold half the membrane back on itself and apply water based adhesive to the roof deck using the mini roller enclosed. A pair of protective latex gloves are enclosed for cleaner application.



Repeat the process on the other half.

Broom over surface of membrane to ease out any creases or bubbles.

Step 4

Trim off any excess rubber sheet around the edges, leaving approx. 50mm overhang.



IMPORTANT

There are various shed designs along the water runoff edge as shown above. We recommend that a thin layer of adhesive is applied to the back of the rubber membrane also and allowed to go semi dry. (It will start to go clear looking).

We also recommend a thin layer of adhesive to any part of the timber area that you would like the rubber membrane to adhere to.

When used in this way, the adhesive acts like an instant bonding adhesive and will give the finished edge needed. Included in the kit is a box of pins that can be used to secure the membrane temporarily until the adhesive has dried fully. (Typically 48 hours).

Step 5

Run a bead of the Permaroof Bond & Seal Sealant (included) along the length of your timber edge bead as supplied by shed manufacturer.

Sandwich the 50mm overhang of membrane between the side of the shed and timber batten.



Nail or screw this through the membrane and into the shed timber, ensuring that the nail fixing is below the bead of sealant line to ensure a watertight seal.

Step 6

Stand back and admire!



Your roof will not leak for at least 50 years!

Permaroof UK Ltd

01773 608 839

permaroof.co.uk

Shop online

permaroofstore.co.uk

EPDM roofing training:

permaroof.co.uk/roofing-training-courses

Further EPDM resources:

permaroof.co.uk/diy-flat-roof-library

Visit our YouTube channel for tutorials:

youtube.com/user/PermaroofOnline/videos