



# Installation Guides

## Installing Permaroof Wall Flashing

We offer a range of roofing and building solutions to tradesmen, stockists, and directly to consumers. Long term solutions to age old problems. Partnering with some of the biggest names in the industry, we have a long history of quality and excellence.



 [www.permarroof.co.uk](http://www.permarroof.co.uk)

 [sales@permароof.co.uk](mailto:sales@permароof.co.uk)

 01773 608839

# EPDM Installation Guides

## Installing the new Permaroof wall flashing



In this tutorial, we're going to show you how to install the new Permaroof wall flashing using Ultrabond in just six easy-to-follow steps.

Wall flashing is an important part of the process of installing EPDM roofing systems where there is an upstanding wall, such as with a flat roof extension project.

**For more installation guides, please visit the Permaroof resource library at:**

[permaroof.co.uk/diy-flat-roof-library](https://permaroof.co.uk/diy-flat-roof-library)

## Step One

Grind out the chase using an 8mm thickness blade.



## Step Two

Bond the EPDM membrane up the wall, leaving it just short of the chase.



## Step Three

Apply Permaroof Ultrabond to the reverse of the Permaroof Wall Flashing, ensuring a continual 5mm bead.

For the best results, use the Ultrabond foil applicator and refill pack, as it offers high levels of control and consistency.



Buy securely online at:

[permaroofstore.co.uk/ultrabond](https://permaroofstore.co.uk/ultrabond)



### IMPORTANT:

*To avoid any warping in hot weather, it is crucial you apply the Ultrabond adhesive to the reverse of the trim.*

*It is as strong as a mechanical fix, and the trim will warp if not used as advised.*



## Step Four

Insert the wall flashing into the chase, gently using your palm of your hand to push it into position.



The Permaroof Ultrabond will sandwich between the flashing and the EPDM membrane, ensuring adhesion.

This also acts as a water block to stop any water ingress from the bottom of the trim.

## Step Five

If you need to use more than one wall flashing, always allow a 3mm gap and make a joint clip out of a 50mm section of wall trim.

Cut off the 'fir tree' part and insert at the back of the wall flashing. Simply butt the next trim up but remember to leave a 3mm expansion space.



## Step Six

Seal up the chase with the Permaroof Ultrabond.

This gives it the finishing touch and ensures a first-class seal.



Fig 7: Sealing up the chase with Permaroof Ultrabond.

And you're done.

If you'd like to learn more about EPDM installation, Permaroof UK Ltd offers industry-leading EPDM application training courses for trade flat roofers and homeowners.

Courses are held weekly at our purpose-built training centre located at our headquarters in Derby.

**Find out more about EPDM application training courses at:**

[permaroof.co.uk/epdm-roofing-training-courses](http://permaroof.co.uk/epdm-roofing-training-courses)

## Permaroof UK Ltd

01773 608 839

[permaroof.co.uk](http://permaroof.co.uk)

## Shop online

[permaroofstore.co.uk](http://permaroofstore.co.uk)

## EPDM roofing training:

[permaroof.co.uk/roofing-training-courses](http://permaroof.co.uk/roofing-training-courses)

## Further EPDM resources:

[permaroof.co.uk/diy-flat-roof-library](http://permaroof.co.uk/diy-flat-roof-library)

## Visit our YouTube channel for tutorials:

[youtube.com/user/PermaroofOnline/videos](https://youtube.com/user/PermaroofOnline/videos)